



## Wiring for A/V Equipment and Lighting

- Any electrical wires or cables used for a TV, stereo equipment or lighting should be secured to the cabinetry and covered to prevent snags on the mattress and mechanism.


### Television

- Wiring and cables for TV and stereo equipment should be routed flush to the back of the TV panel and directly out through a side panel into a side cabinet, preferably the side closest to the wall outlet or power supply. Another option is to route the cables flush with the back of the TV panel directly to the side panels and out the back, through the rail guide bolster.
- Secure cables flush with the interior of the cabinetry. Do not place cable-securing devices in the area where the mattress travels to avoid damaging the mattress cover.

### Lighting

- Lighting fixtures placed at the top of the TV opening should be mounted below the chain system alcove (if used). Additional cabinetry for mounting your lighting should be fabricated if your lighting fixture exceeds 1" in height.

Inside of Cabinet, back of TV Panel



\*Please send your Zoom-Room designs or drawings to [luke@zoom-room.com](mailto:luke@zoom-room.com)  
or fax them to (305) 677-9278 for review before constructing your cabinet.  
Call **(888) 211-1120** with any questions.